

NASA Glenn Propulsion Systems Lab: Update on Calibration Testing

Judith F. Van Zante

NASA Glenn Research Center



2015-06 SAE International Icing Conference

Prague, Czech Republic

Agenda

- PSL Icing Configurations and Capabilities
 - Engine
 - Driven Rig
- Icing/Ice Crystal Cloud Characterization
 - Water Content
 - Particle Size
 - Uniformity
 - Particle Temp


Icing Calibration Configurations



Modification upstream of spraybars

Aero-Thermal Cal Duct
Pres., Temp., Rel. Humidity

Tomography &
Raman Duct



Cloud Calibration Duct
Water Content, Particle Sizing

PSL Operating Range – Icing System

Specification	Min	Max
Engine / Rig Dia. (in cm)	24 60	72 180
Air Flow Rate (lbm/s kg/s)	10 5	330 150
Altitude, pressure (kft km)	4 1.2	50 15
Total Temp (°F °C)	-60 -50	50 10
Mach Number	0.15	0.80
TWC (g/m ³)	0.5	8.0 *
MVD (um)	15	>100 #

* Evidence that probe under-measured

Particles larger than ≈ 60 um are NOT fully glaciated.

Setting Conditions in PSL


Given the atmospheric environment (P_{amb} , T_{amb} , Mach) of concern,
Provide the static conditions (P_s , T_s , Mach) at the inlet plane of either

- Engine (fan face conditions)
- Driven Rig (LPC inlet, etc)

Define target cloud (TWC, MVD)


- Appendix D/P
- Appendix C
- Large Drop

Conduct calibration
toward request to
see what PSL can cover.



(from Aircraft Engine Design, Mattingly)


PSL-3 Envelope




PSL Icing Cloud Hardware

Spray Bars – Cloud Generation

- Ten Spray Bars; total of 110 **Standard** nozzles and 112 **Mod1** nozzles.
- Each nozzle is individually controlled.
- Nozzle controls:
 - **Pair**, atomizing air pressure: 5 – 90 psid, Tair temperature: 45 – 180 F.
 - **Pwat**, water pressure: 10 – 300 psid, Twat temperature: 45 – 180 F.
 - **DeltaP** = DP = (Pwat – Pair)
 - SBCA, Spraybar cooling air.
P: 5 – 40 psid, T : -40 – 40 F.



Full (every) or Half (every other) Pattern




(Pair, DeltaP) => (MVD, TWC)

At a given air mass flow rate

Water Content Instruments – IKP

Iso-Kinetic Probe


SEA Inc.



Ice Catch
Tube system
not
completed
for the May
2015 Entry.


Water Content Instruments – Hot wire

Multi-Wire (TWC & LWC) (MW)



2-mm reverse half-pipe (083)
2-mm half-pipe (TWC)
0.5-mm wire (021)
*Collection Efficiency Corrected**

Robust Probe (TWC only) SEA Inc. (RP) ribbed (rRP)



3.8-mm half-pipe
*No collection efficiency
correction, yet.*

*Ref: Rigby, Struk, Bidwell, "Simulation of fluid flow and collection efficiency for an SEA multi-element probe", AIAA 2014-2752


Water Content – Installation and Analysis

Splitter Plate


Bullet nose
(not recommended)



2012




2014 & 2015





SEA WCM-2000 User Manual

$$IWC \left(\frac{g}{m^3} \right) = \frac{C * P_{sense, wet}}{\underbrace{[L_{evap} + C_{liq}(T_{evap} - T_{amb}) + L_{fus} + C_{ice}(T_0 - T_{amb})]}_{\text{Energy to melt and evaporate ice}} * V * L_{sense} * W_{sense}}$$

MW Response to Temp. change at Altitude (25 um)




Sample TWC Measurements



Config1: Effects of





- Altitude
- Relative Humidity



Config 2: Correlation between
Measured and Calculated


$$\text{Bulk TWC} = \frac{\text{mass_water / time}}{\text{mass_air / time}}$$

Water Content Sensor Comparison




Water Content Sensor Comparison

Sensor Fit Comparison



Sensor/RP v MVD



Drop Sizing Instruments

DMT Inc.



CDP (2 – 50 μm)
Forward Scattering



CIP-GS (15 – 930 μm)
Shadowing




Sample Combined Distributions




Sample MVD Results

Effect of Relative Humidity




Effect of Altitude (Tank Pressure)



Additional Particle Sizing Techniques

Artium, Inc.



Phase Doppler Interferometer

- Particle size
- Particle velocity
- LWC
- Number density

High Speed Imaging

- Particle size (ice & liquid)
- Shape
- LWC
- Number density

Cloud Uniformity Diagnostics

- Grid
 - Supercooled liquid only
 - Low speed only
- Laser Sheet *
- Tomography *

Uniformity is required for Bulk TWC calculation.

* Bencic, T., et. al, “Advanced Optical Diagnostics for Ice Crystal Cloud Measurements in the NASA Glenn Propulsion Systems Laboratory”, AIAA 2013-2678, 2013.

Cloud Uniformity Measurements


Uniformity Grid 3x6 in



Liquid Water Only
Limited Speed, Time



*Long time spray for
visualization only.*

Laser Sheet @ duct exit




Light Extinction
Measurements

Tomography in duct




Cloud Uniformity Results


Grid & Laser Sheet




Laser Sheet @ duct exit



Tomography in duct



	TWC_RP (g/m ³)	Bulk TWC (g/m ³)	Max TWC (g/m ³)	Bulk / RP ratio (%)
Laser Sheet	3.30	2.44	3.74	74.1
Tomography	3.30	2.44	3.58	74.0



Particle Temperature

Raman Scattering – Primer


- Measures surface temperature
- Measures average bulk particle phase – ice or water
- Is a very low light technique, signal can be contaminated by light from other techniques or cell lights

Adding a fluorescent dye greatly helps with signal gain.


Raman Scattering – Particle Phase & Temp.

T. Bencic's bench top results

Raman Spectra of Water & Ice



Raman Area Ratio



Future Tasks

- Continue analysis of May 2015 cloud characterization data
- Implement calibration curves
- Evaluate MVD sensitivity to configuration changes.
- Publish report

With thanks to the PSL Cloud Cal Team:

- **Bryan Rosine**
- **Jonathan Borman**

Questions?

